

MANUAL USE

Our dual zone unit AHB380V3 offers a new option: **SMS Alarm module.**

It allows you to be informed about your curing process.

Also, the operator can communicate with the Hot Bonder to check the status of the cure.

The set-up:

1. Purchase a local SIM card and enter it in a mobile
2. Go to SIM parameter of the mobile
3. Change the initial PIN code by 1234
4. Then put the SIM card into the SMS module

How to use:

1. Plug the SMS module before to switch on the bonder
2. Go to Menu, Login, User: 2 (mini level), Password: 2
3. Go to Cure, New Cure
4. Follow the procedure on page 2: 3 clicks only
5. Do a SMS test before to close the SMS setting screen to check if the SMS module is running properly

To communicate with the hot bonder:

1. Send a SMS from your mobile to SMS module number
2. Message to send is: \$HB+QUID=0000
3. You will get automatically the status on the cure



SMS Module



NB: SMS module number is dedicated to only 1 Hot Bonder.

Page 1/2